



## Motion Computing Software Release Note

Name	<b>OmniPass 6.50.11.1</b>
File Name	<b>OmniPass_v650111.zip</b>
Release Date	January 12, 2010
This Version	6.50.11.1
Replaces Version	All previous 6.x.x versions
Intended Users	<b>Motion C5, F5, and J3400 users</b>
Intended Product	Motion C5, F5, and J3400 Tablet PCs ONLY
File Size	62.5 MB
Supported Operating System	<ul style="list-style-type: none"><li>• Windows XP Tablet Edition 2005*, Version 2002, Service Pack 2 or Service Pack 3 - Installed.</li><li>• Windows Vista, all versions except Windows Vista Home Basic.</li></ul> <p>* Tablet Edition 2005 is included with the free Service Pack 2 download. If you installed Windows XP Service Pack 2 on a Tablet PC, you now have Tablet Edition 2005.</p>

### Fixes in this Release

- Fix trial version issue when updating from 6.0.x to 6.50.11.

### Known Issues and Limitations

If the current OmniPass version is 5.x.x, this package will install as a trial version upgrade that will require an additional upgrade activation fee.

### Installation and Configuration Instructions

#### To install this version update, perform the following steps:

1. Download this update to the directory location of your choice.
2. Unzip the file to a location on your local drive.
3. Back up your existing OmniPass profile (see OmniPass Help for details).
4. Run version 6.50.11.1 setup.exe and follow the prompts.

### Licensing

Refer to your applicable end-user licensing agreement for usage terms.